



Remove the hardware from the leg of the WSM. Slip the bar behind the leg with the bend angled out from the WSM as shown. Use the same hardware to fasten it back together.



Remove the hardware from the leg of the WSM. Slip the bar behind the leg with the bend angled out from the WSM as shown. Use the same hardware to fasten it back together.



Remove the hardware from the leg of the WSM. Slip the bar behind the leg with the bend angled out from the WSM as shown. Use the same hardware to fasten it back together.



Remove the hardware from the leg of the WSM. Slip the bar behind the leg with the bend angled out from the WSM as shown. Use the same hardware to fasten it back together.